



NOTE:

1. ROTATE TOGGLE TO ALIGN WITH CABLE AGAINST END STOP
2. INSERT INTO THRU HOLE
3. TURN TOGGLE 90° ONCE IN THRU HOLE TO SECURE